



- | | |
|----|--|
| 1. | Tripod mount screw (1/4-20 UNF Thread) |
| 2. | Handle mount screw |
| 3. | Handle mount screw slotted head |
| 4. | Alignment pin |
| 5. | O-Ring slot and O-ring |



The vCamDrain tablet mount is installed on the open end of the reel where the pushrod is deployed.

1. Use a flat-blade screwdriver for access to the Philips head screw. Remove this screw.
2. Prepare the adapter by adding a small dab of grease to the O-ring.
3. Align the adapter's alignment pin with the slot in the handle and press the adapter in place.
4. Use a slotted screwdriver to tighten the adapter in place.

